

Gestures on iPhone X

Go Home. Swipe up from the bottom edge to return to the Home screen at any time. See [Home screen](#).

Quickly access controls. Swipe down from the top-right edge to open Control Center. Press firmly on a control to reveal more options. To add or remove items, go to Settings > Control Center > Customize Controls. See [Control Center](#).

Switch between recent apps. Swipe up and pause to show the App Switcher. From any open app, you can also swipe right along the bottom to quickly switch apps.

Ask Siri. Just say, “Hey Siri.” Or hold down the side button and make your request. Siri listens until you release the button. See [Make requests](#).

Use Apple Pay. Double-click the side button to display your default credit card, then glance at iPhone X to authenticate with Face ID. See [Set up Apple Pay](#).

Use Accessibility Shortcut. Triple-click the side button. See [Use accessibility shortcuts](#).

Take a screenshot. Simultaneously press and quickly release the side button and volume up button.

Make an emergency SOS call (all regions except India). Simultaneously press and hold the side button and either volume button until the sliders appear, then drag Emergency SOS. See [Emergency calls](#).

Turn off. Simultaneously press and hold the side button and either volume button until the sliders appear, then drag the top slider to power off. Or go to Settings > General > Shut Down.

Force restart. Press and release the volume up button, press and release the volume down button, then press and hold the side button until the Apple logo appears.

